

Mounting instructions for merry-go-round „flecto“


Item No. 51 4022 401



Diagram 1: Overall view of the play equipment

Mounting instructions for merry-go-round „flecto“

Item No. 51 4022 401



1. Select the location of the play equipment taking into account the required minimum space (see diagram 3: Ø 8100mm).
2. The impact area of a playground equipment with an enforced movement is not allowed to overlap the impact area of other equipment.
According to DIN EN 1176-1, 4.2.8.5.2 shock-absorbing floors must be made on the entire impact area of every equipment that cause forced movement.
3. Carry out excavation work for the foundation as shown in diagram 2. After excavation compress the foundation floor.
Note: The merry-go-round is installed at play level. Pay attention to items marked „play level“ at play equipment!
4. Set up the concrete foundation according to diagram 2 with central, horizontal reinforcement. Pour the supplied foundation anchor in the foundation so that the upper angle frame is horizontal and flush with the foundation surface.

Reinforcement plan: Concrete foundation with reinforcement

Main foundation: BSt 500S

Stirrups Ø 8 mm lengthwise and cross

Concrete cover $h' = 3$ cm

Concrete quality class C 20/25 - C 25/30

Legende

 stoßdämpfender Boden
shock-absorbing floor

 Beton
concrete

 gewachsenes Erdreich
natural ground

Hinweis Bodenabstand:
loses Bodenmaterial mind. 300mm
festes Bodenmaterial mind. 400mm

Note ground clearance:
loose ground material min. 300mm
solid ground material min. 400mm

Diagram 2: Foundation plan

No warranty for damages because of backwater / condensation water at the tube. Take care that the drainage in the ground is sufficient.

Mounting instructions for merry-go-round „flecto“

Item No. 51 4022 401




Diagram 3: Top view

5. After a setting period of 10 – 14 days, depending on weather conditions and foundation size, fill up and compress the holes between the foundation and the foundation hole with excavation.
6. Clean the foundation surface and place the play equipment on the foundation anchor and screw it down.
7. Cover the entire impact area with fall protection according to the required drop height in accordance with EN 1176-1.
Critical drop height 650 mm
Recommended surface material: grass, sand, wood chip, gravel, synth. fall protection.
8. Do not allow children to use the equipment before the installation has been finished.

Attention: If the play equipment has been incompletely installed or partly dismantled when carrying out maintenance and repair work, this may lead to particular risks of injury for the user. For this reason, make clearly visible that the equipment shall not be used in such cases.

NOTE: Play equipment, which contain components made of stainless steel should not come with „normal“ steel parts in contact. Those steel parts may rub off and leave small steel particles in combination with moisture brown rust stains. If such corrosion occur on stainless steel parts, they are fine with an abrasive (240 grit) to remove.

Please take care when transporting and setting up the fact that the components are made of stainless steel with no „normal“ steel parts in contact.

Mounting instructions for merry-go-round „flecto“

Item No. 51 4022 401



In order to preserve a good visual appearance of your stilum playground equipment over a long period one should take care of maintenance of the stainless surface even despite of their corrosion resistance.

Especially areas, which can not be reached by rainfall should be frequently cleaned from dirt and deposits due to air pollution and dirt caused by the atmosphere.

Light soiling can easily be removed by using a high pressure cleaner.

For persistent deposits use a clean cloth moistened with a special liquid cleaner (e.g. on phosphoric acid) and rinse off with clear water after a short application time. During cleaning with mild abrasive components, only wipe over stainless steel surface in polishing direction.

For heavily soiled surfaces, polishes can be used (e.g. for cleaning chrome on cars) or for greasy and oily dirt alcoholic cleaning agents and solvents (e.g. ethyl alcohol, isopropyl alcohol or acetone).

However, it should be noted that the dissolved soiling is not spread over the surface again.

Do not use any chlorid or hydrochloric containing cleaning products nor scouring powder, bleaching - or silver polish cleaner. Cleaning intervals depend on type and degree of soiling as well as on demands made on optical characteristics.

Therefore cleaning is advisable at intervals of six to twelve months – whereby in the case of strong soiling it is appropriate to clean the playground equipment at intervals of three to six months.