

Mounting instructions for playpoint without impact protection „flovera“


Item No. 51 3410 401



Diagram 1: Overall view of the play equipment

Mounting instructions for playpoint without impact protection „flover“

Item No. 51 3410 401



1. Select the location of the play equipment taking into account the required minimum space (see diagram 3: Ø 3500 mm).
2. Carry out excavation work for the foundation as shown in diagram 2. After excavation, compress the foundation floor.
Note: The playpoint is installed at play level.
3. Set up the concrete foundation according to diagram 2 with central, horizontal reinforcement. Pour the supplied foundation anchor in the foundation so that the upper angle frame is horizontal and flush with the foundation surface.

Reinforcement plan: Concrete foundation with reinforcement

Main foundation: BSt 500S

Stirrups Ø 8 mm lengthwise and cross

Concrete cover $h' = 3$ cm

Concrete quality class C20/25

4. After a setting period of 10 – 14 days, depending on weather conditions and foundation size, fill up and compress the holes between the foundation and the foundation hole with the excavation.
5. Clean the surface of the foundation. Place the play equipment on the foundation anchor and screw it down. Create topsoil.
Recommended surface material: optional, with the exception of sand
Note: The ground should be smooth and free of edges.
6. Do not allow children to use the equipment before the installation has been finished.

Mounting instructions for playpoint without impact protection „flova cala“

Item No. 51 3410 401




Diagram 3: Top view

Note for the temporary disassembly:

7. Remove the 4 screws beneath the standing position (see diagram 4a).
8. Take out the stucked pipe.
Note: 180mm of the pipe still protrudes and poses a tripping hazard.
9. Cover the remaining pipe with the plastic cap included in the delivery (see diagram 4b).

Attention: If the play equipment has been incompletely installed or partly dismantled when carrying out maintenance and repair work, this may lead to particular risks of injury for the user. For this reason, make clearly visible that the equipment shall not be used in such cases.

NOTE: Play equipment, which contain components made of stainless steel should not come with „normal“ steel parts in contact. Those steel parts may rub off and leave small steel particles in combination with moisture brown rust stains. If such corrosion occur on stainless steel parts, they are fine with an abrasive (240 grit) to remove.

Please take care when transporting and setting up the fact that the components are made of stainless steel with no „normal“ steel parts in contact.

Mounting instructions for playpoint without impact protection „flova cala“

Item No. 51 3410 401




Diagram 4a: Temporary disassembly




Diagram 4b: Rain protection

In order to preserve a good visual appearance of your stilum playground equipment over a long period one should take care of maintenance of the stainless surface even despite of their corrosion resistance.

Especially areas, which can not be reached by rainfall should be frequently cleaned from dirt and deposits due to air pollution and dirt caused by the atmosphere. Light soiling can easily be removed by using a high pressure cleaner.

For persistent deposits use a clean cloth moistened with a special liquid cleaner (e.g. on phosphoric acid) and rinse off with clear water after a short application time. During cleaning with mild abrasive components, only wipe over stainless steel surface in polishing direction.

For heavily soiled surfaces, polishes can be used (e.g. for cleaning chrome on cars) or for greasy and oily dirt alcoholic cleaning agents and solvents (e.g. ethyl alcohol, isopropyl alcohol or acetone).

However, it should be noted that the dissolved soiling is not spread over the surface again.

Do not use any chlorid or hydrochloric containing cleaning products nor scouring powder, bleaching - or silver polish cleaner. Cleaning intervals depend on type and degree of soiling as well as on demands made on optical characteristics.

Therefore cleaning is advisable at intervals of six to twelve months – whereby in the case of strong soiling it is appropriate to clean the playground equipment at intervals of three to six months.