Mounting instruction bench "tabula"

Item-No. 57 1028 401





Diagram 1: Overall view

Mounting instruction bench "tabula"

Item-No. 57 1028 401






Diagram 2: Foundation plan

gewachsenes Erdreich natural ground Select the location.

300

- 2. Carry out excavation work for two foundations as shown in diagram 2. After excavation compress the foundation floor.
- 3. Set up the concrete foundations acc. to diagram 2 in the quality class C 20/25 with central, horizontal reinforcement.
- 4. After a setting period of 10 14 days, depending on weather conditions and foundation size, fill up and compress the holes between the foundation and the foundation hole with excavation.
- 5. Clean the foundation surface. Align the bench combination and screw the base plates to the foundation using the included heavy-duty dowels.
- 6. Create top soil with an even ground level.
- 7. Do not allow anyone to use the urban furniture before the installation has been finished.

Attention: If the urban furniture has been incompletely installed or partly dismantled when carrying out maintenance and repair work, this may lead to particular risks of injury for the user. For this reason, make clearly visible that the equipment shall not be used in such cases.

NOTE: Urban furniture, which contain components made of stainless steel should not come with "normal" steel parts in contact. Those steel parts may rub off and leave small steel particles in combination with moisture brown rust stains. If such corrosion occur on stainless steel parts, they are fine with an abrasive (240 grit) to remove.

Please take care when transporting and setting up the fact that the components are made of stainless steel with no "normal" steel parts in contact.